



SCHROTH RACING INDI SEAT KIT

QUICK CURE

USER GUIDE, SAFETY & INSTALLATION INSTRUCTIONS

Please ensure that you read and follow all the warnings, instructions and stages in this Manual.

EA 13.3
Edition: 06/2018

Content

WARNINGS & Information Boxes	01
Preparation & Timing & Temperature	02 - 03
"Dry Fit" – No Resin, No Water	03 - 04
Quick Cure Resin	05 - 06
Final Fitting	07 - 08
Seat Finishing	08 - 09
Addresses, Trademarks & Copyrights	10

If you have any questions after reading this manual, please contact:

iNDiseat@SCHROTHRacing.com

www.schroth.com/indiseat

WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.

WARNINGS & INFORMATION BOXES

DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

SAFETY INSTRUCTIONS

SAFETY INSTRUCTIONS signs indicate specific safety-related instructions or procedures. They contain important hints to help you make & install, use and maintain your SCHROTH Racing iNDi Seat insert properly and effectively.

WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.

PREPARATION & TIMING & TEMPERATURE

Welcome to your SCHROTH Racing iNDi seat kit
Safety Data Sheets can be obtained upon request.

Please eMail: iNDiseat@SCHROTHRacing.com

PREPARATION & TIME

Before making your seat please ensure the following:

Time Required - a minimum of 2hours will be required from start to finish to achieve a satisfactory result. If you (and the driver) do not have this amount of time available it is not recommended to begin this project.

SAFETY INSTRUCTIONS

On receiving & opening your kit please check contents are correct and free from damage.
Our unique resin can be stored at any temperature.

SAFETY INSTRUCTIONS

All sharp edges and objects within the car and seating area must be covered – tape over or cover ALL sharp edges where necessary. This will ensure the bag material does not get punctured or damaged during the fitting process.

Remove all racing belts from the desired seating position.

Make sure the pedals & steering wheel are adjusted for the driver.

Make sure the driver has his/her regular race suit, FHR/HANS device, boots & racing helmet for the seat fitting.

Useful kit to also have is, tape measure, marker pen and stopwatch.

⚠ WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.

WORK AREA & TEMPERATURE

A working area with sufficient room to move around the car along with laying out the iNDi seat bag is required. Our unique resin is NOT temperature sensitive so the insert can be made at any temperature.

DRY FIT - No RESIN, No Water

It is vital that a DRY FIT is performed before any of the Resin & Water is used. This will get the driver used to how the seat should feel, and will also enable you to determine the correct placement and volume of beads.

Lay the bag out on a flat smooth surface, and spread the beads evenly over the whole area of the bag. Stretch the bag lightly by pulling at the corners to ensure there are no creases.

With a vacuum source (optional foot pump not included) and hose attached to the valve, (To open the valve hold the black tap and press the button at the back of the tap) Apply a vacuum until the bag starts to take on an "orange-peel" effect, and the bag is fairly rigid. This will ensure the bag will hold its shape when it is fitted into the cockpit.

SAFETY INSTRUCTIONS

During the Dry Fit and Final Fitting, pedals and steering wheel should be set in the driver's preferred position. Headrest, where applicable needs to be fitted and driver needs to be wearing their helmet, FHR/HANS device, racing overalls and boots.

Fit the bag into the cockpit or seat shell, and press the bag firmly into position; by slowly releasing the vacuum it may help to achieve this fit. Ideally, the bag should be placed with the black tap at the top; allowing for easier access to adjust the vacuum. For the vacuum to function optimally, the tap should be placed in an area where beads will be present so the bag does not get pulled into the tap under suction.

Seat the driver in the car, being careful to disturb the bag as little as possible. The driver will now have to achieve the desired position by displacing the beads within the bag. To aid in this process, it may help by releasing the valve allowing more air into the bag.

At this stage, if the driver is finding it difficult to achieve the desired position, it may be because the bead volume in the bag is too high, and therefore must be decreased.

To decrease the volume of beads, the bag will have to be removed from the cockpit, and then remove the black tap. Once the black tap is removed you can slowly remove some of the beads. Keep track of how many litres of beads you have removed; you will need to know this later when mixing in the resin.

⚠ WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.

WARNING

The driver's helmet must be under the roll hoop (open cockpit cars) as defined in the sporting and/or championship regulations. Refer to the current regulations for the minimum height of this clearance. Failure to seat the driver under the roll hoop may result in serious personal injury or death.

Taking considerable time at this stage is necessary, ONLY by altering the amount, and position the beads around the bag, drivers will then be able to achieve the optimum seating position.

WARNING

The steering wheel must be able to move freely lock to lock. Care must be taken to make sure the drivers legs do not inhibit or foul the steering wheel operation. Also the driver's hips and shoulders must be level and central.
Failure to check steering wheel clearance or seat driver level or central may result in serious personal injury or death.

Remember, by slightly adjusting the amount of vacuum, you will be able to "firm-up" or "soften" the bag in position, and allow the driver to forcibly move around, so to position the beads into the areas where support is required. Equally, it might prove helpful for drivers to have outside assistance so to shape the bag around areas where extra lateral support may be required.

Once the driver has achieved the desired seating position, apply vacuum to the bag to maintain the shape and form of the seat insert. Then the driver must (carefully) extract themselves from the cockpit. At this stage it will be advantageous using a permanent marker pen to measure and mark on the bag the various thicknesses of the beads in key areas such as back, lumbar, and legs. Also marking specific support areas in relation to the driver and cockpit environment, as this will aid when after having applied the resin, the initial bag layout can be replicated.

WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.

QUICK CURE RESIN

We have developed this quick cure resin so you can make an insert at any temperature. Our quick cure resin also cures much faster, regardless of the ambient temperature. Water is the “activator” which is simpler and more user friendly than other resins.

Please see Table 2 for new working times.

MIXING RESINS

Well done - now you have completed the Dry Fit, you now know how many beads you need to make the seat and you know how the seat will be fitted. You are now ready to mix in the resin and water.

Table 1: Ratio Table Bead / Resin & Water

Bead Volume (litre)	Resin Volume (litre)	Water Volume (ml)
10	0.5	100
20	0.6	100
25	0.7	100
30	0.8	100
40	1.0	150
50	1.3	150
70	1.7	300

NOTICE

Do not dispose of excess resin in waterways.

WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.

CAUTION

When handling, preparing & mixing the resin and water, protective eye wear and gloves must be worn. Do not drink or ingest the resin. Do not use a naked flame near the resin or near the seat while curing.

Failure to use protective equipment may result in serious personal injury or death.

Table 2: Working Times

Working Time	20-25 minutes from mixing the water with the beads and resin
Curing Time	working time plus 10 min = 35 minutes: The seat insert will be cured and ready to cut/trim at 35 minutes from mixing the beads and water

PLEASE NOTE: It is advisable to use a stopwatch and to stop the driver moving after 20-25 minutes so to avoid any cracks in the seat insert as it cures completely.

SAFETY INSTRUCTIONS

Adjust the resin and water volumes using the Table 1: Bead/Resin & Water Ratio Table & measuring container supplied. Care must be taken in having the correct amount of each component as this will affect the finished seat.

STEP 1: Mix the **RESIN ONLY** first. Without the water the resin is inert and this will allow you to mix the resin thoroughly getting good coverage over the beads.

Important: Take around 5 minutes to combine the resin only [**NO WATER**] completely with the beads. Use a “kneading” action to mix and move the mixture around the bag.

Remove the black tap from the bag. Using the supplied funnel pour the resin into the bag.

Careful: DO NOT over stress the bag in this area and hold the opening in a central position just above the beads. Insert the funnel and pour the resin straight onto the beads, trying to avoid it running down the inside of the bag walls. Re-fit the black tap once all the resin is added, and start blending the resin with the beads.

STEP 2: Now start the stopwatch. You have **25 minutes** working time before the mix is almost cured and additional changes are not possible.

STEP 3: Pour the water into the bag and mix with the resin coated beads. You will feel the beads change to a “looser feel”. Don’t spend too long, just quickly mix the water (max. 1-2 Min.).

Move the beads back into position as per the DRY FIT. Use measurements and pen markings to assist you in getting the insert into the same shape as the DRY FIT. Then apply strong Vacuum.

WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product’s ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.

FINAL FITTING

CAUTION

During the final fitting stage, pedals and steering wheel should be set in the driver's preferred position. Headrest, where applicable needs to be fitted and driver needs to be wearing their helmet, FHR/HANS device, racing overalls and boots.

Care must be taken to remove creases and folds from the casting bag otherwise this will leave cracks and fissures in the finished seat. When applying the final vacuum, vacuum the seat so it holds the desired shape and form, but not too much vacuum that the seat shrinks or deforms.

The final fitting is a repeat of the dry fit see page 3, except that the beads are now mixed with the resin & water so to produce a solid end product.

Using the pen markings made on the bag and measurements during the dry fit stage, spread the beads around so to replicate the various thicknesses of beads required in each location marked.

Take care adjusting the vacuum at this stage, as the mix behaves differently than under dry fit vacuum conditions.

WARNING

The steering wheel must be able to move freely lock to lock. Care must be taken to make sure the drivers legs do not inhibit or foul the steering wheel operation. Also the driver's hips and shoulders must be level and central.

Failure to check steering wheel clearance or seat driver level or central may result in serious personal injury or death.

In order to achieve the optimum final position for the driver, all participants involved must work together to aid in this process. Remembering that there is ONLY 25 minutes working time at this stage. The driver must (with aid if required) shift the beads around by forcibly moving around in the seat, to displace the beads to the areas required.

The unique properties of the bag are designed for this purpose, and the bag is extremely robust and „stretchy“, but please do not over stress the bag.

It is vital that in order to produce a quality finished product, that as many creases as possible are removed from the surface in contact with the driver. A crease or fold in the bag may cause

WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.

a fissure or deep crack which will weaken the seat once hardened. "Pulling-out" firmly on the bag material where creases or folds have developed will allow the bead mix to form together. Careful kneading and moving of the beads at the same time will also aid in this process.

Only when the driver is completely satisfied with the seat position and profile, should you apply vacuum to the bag to maintain the shape and form of the seat insert, with the driver maintaining his/her desired position.

Once all the air has been removed from the bag – the driver needs to stay in position until the 25 minute working time is finished. You may need to apply vacuum during this process to keep the required shape as due to the unique resin mix a certain amount of "gassing" occurs.

Keep track of the time and always remind the driver of the time he/she has been working with the resin filled seat. Remember you have 25 minutes from when you mixed the resin and water until the seat begins to harden and set.

Important Note: Our unique resin and water mix is **not** temperature sensitive. The mix will cure at the same rate whatever the temperature. Therefore care must be taken to adhere to mix ratios and stopwatch times on page 6.

NOTICE

Leave the bag + driver in place for at least the minimum 25 minute curing period.

SEAT FINISHING

The bead & resins mix will set sufficiently for the seat to be handled after 35 minutes, from mixing in the water before the seat is trimmed to its final profile

Once the seat is cured, please remove carefully. Give some thought beforehand to the best way of removing the cured seat.

CAUTION

When handling knives of any sort extra care must be taken. Protective gloves and eye wear must be worn when trimming your finished seat. When using a hot knife a mask is also required.

WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.

SAFETY INSTRUCTIONS

When trimming and finishing the seat the driver should be present for feedback. Before covering the seat we recommend the driver tests the seat on track. Adjustments and additional trimming may be required after testing on track.

Cut away any excess parts of the bag, and begin trimming away excess material to allow clearance, and easy future fitment/extraction of the seat itself. We recommend using a hot knife and sanding block for a perfect trim. **Use of mask and eye protection is required.**

Allowances should be considered for the straps of the Racing (crotch/lap/shoulder) belts, as well as items such as a FHR/HANS device and headrest, when trimming the seat.

WARNING

When covering your seat, consult your Championship Regulations first. We always recommend a fire retardant covering.

Failure to cover your seat with the correct covering may result in serious personal injury or death.

The final product can then be covered in a variety of options.

Professional finishing is available from our Official Technical Partner Cobra Seats www.cobraseats.com. We can supply prices on request, just contact us at iNDiseat@SCHROTHRacing.com and we will be happy to send you our price list for covering your SCHROTH Racing iNDi seat.

Well done, you have now read the detailed & important user guide and you are now ready to make your SCHROTH iNDi race seat.

If after reading this detailed guide you are still unsure, please feel free to contact us:

iNDiseat@SCHROTHRacing.com

WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.

ADDRESSES, TRADEMARKS & COPYRIGHTS

ADDRESS:

SCHROTH Safety Products GmbH

Im Ohl 14

59757 ARNSBERG

GERMANY

Phone: +49 (0) 2932-9742-0

FAX: +49 (0) 2932-9742-42

eMail: germany@schroth.com

www.schroth.com

SCHROTH® reserves the right to incorporate any technical changes or further development in its products without notice.

Our web site will inform you about actual instructions and products.

Also regional representatives and further importers are listed by countries.

REGISTERED TRADEMARKS:

SCHROTH® is an international registered trademark of SCHROTH Safety Products GmbH, Im Ohl 14, 59757 Arnsberg, Germany

iNDi Seat® is a registered trademark of RAS Ltd., UK

HANS® is a registered trademark of Simpson Performance Products Inc., USA

COPYRIGHTS:

The copyrights of this "Installation and Operating Instructions" are property of SCHROTH Safety Products GmbH, Im Ohl 14, 59757 Arnsberg, Germany.

Copyright of this in part or in whole, on paper, on film or electronically is allowed only after written permission by SCHROTH Safety Products GmbH, Im Ohl 14, 59757 Arnsberg, Germany.

© 2018, SCHROTH Safety Products GmbH

⚠ WAIVER

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from any injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK. No warranty or representation is made as to its ability to protect against serious injury or death, which might result from circumstances beyond the control of SCHROTH Safety Products or SCHROTH Racing. Racing is dangerous! The USER assumes the risk.